



### **EN - Instruction Manual Timer 4805**

Turn clockwise to 55 minutes (make sure to turn clockwise to 55 and not exceed 0 firstly each time). Then turn counter-clockwise to the time required.

There will be 8 seconds alarm sound when time is up.

Do not turn counter-clockwise directly from 0 to keep timer from damaging

Use soft dry fabric to clean the timer. Do not dip in the water.

### **FR - Notice d'utilisation**

Avant chaque utilisation, remonter le minuteur jusqu'à 55 minutes (ne pas dépasser la position 0), positionner ensuite le pointeur sur le temps désiré.

Le minuteur sonnera au bout du temps programmé pendant 8 secondes.

Ne pas forcer le mécanisme en sens inverse sous peine d'endommager l'appareil.

Utiliser un tissu doux et sec pour le nettoyer.

Ne pas plonger le minuteur dans l'eau.

### **ES – Instrucciones de utilización**

Para programar el temporizador, antes de cada utilización, remonte el puntero hasta los 55 minutos (no más que 55 minutos). Después muévelo, pero esta vez en dirección contraria a las agujas del reloj hasta encontrar el tiempo deseado.

El minuterero sonará al final del tiempo programado durante 8 segundos.

Use un paño suave y seco para limpiarlo.

No sumerja el temporizador en agua.