



MANUEL D'INSTRUCTION 4815



Caractéristiques techniques

Plage de température: -40°C to +230°C

Précision: $\pm 0.5^{\circ}\text{C}$ entre 0°C et 100°C

Résolution: 0.1°C

Pile: 3 X AAA fournies

°C/°F - ON/OFF - Hold – IP67 - Calibration 0°C - Auto off 30 minutes – compatible induction

Boîtier et sonde aimantés

Câble d'un mètre avec sonde inox 100mm

Compatible induction

Mode d'emploi

Pour changer les piles, retirer le cache batterie à l'aide d'un tournevis, remplacer la pile et refermer le cache.

Marche/arrêt: Appuyer sur "On/Off" pour mettre en marche le thermomètre; Appuyer sur "On/Off" pour éteindre l'appareil. L'appareil s'éteint après 30 minutes d'inactivité.

Hold: Appuyer sur "Hold" pour maintenir affichée la température actuelle à l'écran

°C/°F: Retirer le cache batterie, appuyer sur le bouton °C/°F pour changer l'unité de mesure.

Précautions d'emploi


Pour obtenir une lecture fiable, immerger la sonde inox d'au moins 30 mm dans la substance à contrôler.

ON/OFF

Allumez l'appareil en appuyant sur le bouton ON/OFF. Pour l'éteindre, appuyez à nouveau sur le bouton ON/OFF. Le thermomètre s'éteint automatiquement après 30 minutes.

HOLD

Appuyez sur le bouton Hold pour maintenir à l'écran la lecture de la température actuelle. Appuyez à nouveau sur ce bouton pour libérer la fonction.



Calibration 0°C

Retirez le cache de la batterie pour trouver ce bouton.

Préparez un seau de glace avec un peu d'eau.

Lorsque la température se stabilise entre -0,2°C et 0,2°C. Appuyez sur le bouton 0 Cal pour remettre la température à 0°C.

Passer de °C/°F

Retirez le cache de la batterie pour trouver ce bouton.

Appuyez une fois pour passer de °C à °F ou de °F à °C.



USER MANUAL 4815



Specifications

Temperature Range: -40 to +230 C

Precision: $\pm 0.5^{\circ}\text{C}$ from 0°C to 100°C

Resolution: 0.1°C

Battery: 3 X AAA battery included

$^{\circ}\text{C}/^{\circ}\text{F}$ - ON/OFF - Hold - IP67 - 0°C Calibration - Auto off 30 minutes - Induction compatible

Magnetic backside and probe.

1 meter cable with 100mm stainless steel probe

Induction compatible

User manual

To change the battery, remove the battery cover with a screwdriver, replace the battery and close the cover carefully.

On/Off: Press "On/Off" to turn on the thermometer. Press "On/Off" to turn off the thermometer.

The thermometer will turn off automatically after 30 minutes without use.

Hold: Press "Hold" to keep on the screen display the current temperature.

$^{\circ}\text{C}/^{\circ}\text{F}$: remove the battery cove, press the $^{\circ}\text{C}/^{\circ}\text{F}$ button to change the unit of measurement.

Safety use

To have a reliable reading insert the probe at least 30 mm into the substance which needs to be controlled


ON/OFF

Turn ON by pressing the ON/OFF button. Turn Off by pressing the ON/OFF button again.

The thermometer will turn off automatically after 30 minutes.

HOLD

Press Hold button to hold the screen for current temperature reading. Press again to release the hold.



0°C calibration

Remove the battery door to find this button.

Ready a bucket of ice. Add little water to the ice.

When the temperature stabilizes at -0.2°C to 0.2°C . Press the 0 Cal button to reset temperature to 0°C .

$^{\circ}\text{C}/^{\circ}\text{F}$ switch

Remove the battery door to find this button.

Press once to switch from $^{\circ}\text{C}$ to $^{\circ}\text{F}$ or $^{\circ}\text{F}$ to $^{\circ}\text{C}$.

254 rue Foch Vaux-le-Pénil 77000 - France

V1. 05/09/2022